Maintenance Schedule

WARNING:

TO AVOID SERIOUS INJURY AND/OR DEATH, NEVER PERFORM ANY VEHICLE SERVICE OR MAINTENANCE WHILE THE ELECTRICAL LEAKAGE WARNING IS ILLUMINATED. REFER TO LEAKAGE DETECTION IN THE ELECTRICAL SECTION AND RESOLVE THE LEAKAGE CONDITION PRIOR TO BEGINNING OTHER REPAIRS.

Regular Interval	Item	Service
Daily service (by owner)	Batteries	Charge batteries after each use.
Monthly service (by owner or technician)	Batteries	Flooded Only-Check electrolyte level. Add distilled or demineralized water as necessary.
		Wash battery tops and clean terminals with baking soda/water solution. Dispose of wastewater properly.
	Tires	Check air pressure and adjust as necessary.
	General Vehicle	Wash battery compartment and underside of vehicle. Dispose of the wastewater properly.
Semi-annual service by a qualified technician	Brake system	Check brake shoes.
		Lubricate brake slides.
		Brake linkage and pivots
	Front wheel alignment	Check and adjust as required.
Annual service by a qualified technician	Batteries	Test batteries. Check for proper battery terminal tightness.
	Gearbox	Drain/fill gearbox fluid.
	Front suspension	Inspect and lubricate front wheel bearings.
	Brake system	Pushrod locknut for tightness.